

Is there a reset button/pin/pad?

We don't have a reset button/pin/pad. Only removing the cable from microUSB.

Revision #1

Created 23 February 2023 12:38:11 by Sebastian Jarosz

Updated 24 February 2023 11:17:13 by Sebastian Jarosz