

Does URVE Pi have a built-in watchdog? Does it run in the basic configuration?

It doesn't run in the basic configuration, but adding it to the kernel is trivial, as well as turning it on and "feeding" it.

Revision #2

Created 24 February 2023 09:16:16 by Sebastian Jarosz

Updated 24 February 2023 09:17:49 by Sebastian Jarosz